

epati

Ethernet Status

Product: Antikor v2 - Layer2 Tunnel
Guides

Ethernet Status

It shows the status of the physical Ethernet interfaces. Lights on the back of the server will light up when the Lights button on the Notification LED is pressed. In this case, it becomes clear which Ethernet is named by which port.

Ethernet Status

#	Management Status	Network Cable Status	Ethernet Name	Name	Media Type	MAC Address	MTU	Notification Led
1	Enabled	Unreadable Information	bge0	LAN1	none)	00:e0:66:c1:0c:2f	1500	Hardware not supported
2	Enabled	Cable attached	bge1	WAN1	100baseTX	00:e0:66:c4:58:d9	1500	Hardware not supported

FIELD	DESCRIPTION
Administrative Status	Indicates status of Ethernet interface.
Ethernet Cable Status	Indicates Ethernet interface's connection status.
Ethernet Name	Indicates name of Ethernet interface of System.
Name	Indicates name of Ethernet interface of Antikor.
Media Type	Indicates connection speed.
MAC Address	Indicates MAC address of Ethernet interface.
MTU	Indicates package size. (Maximum Transfer Unit)
Notification LED	LED may be turned on if hardware supports this.

