

epati

Hotspot Settings

Product: Antikor v2 - Next Generation Firewall
Guides

Hotspot Settings

Users can provide time or quota -based access.

Default quota

Quota boundaries can be regulated with pre -defined templates.

User Quotas

They are the computers to be used on the total time or data transfer sum (MBYTE) on the network. According to the quota templates defined in the default quotas section, it is the section in which users are included in the quota group.

Open Hotspot Sessions.Hotspot Monitor>You can follow page
The Bandwidth Monitor Service must be started in order for the quota information to be processed smoothly!

Hotspot Settings

User Quotas User Contract

Reload Add

XLS CSV PDF

Hide/Show

Records Per Page

25

OK

Filter

Reset Filter

User Informations	Duration	Quota	Period	Remaining Time	Remaining Quota	One Time	Logout Option	Max Login Limit per Person	Last Access Time	Actions
Default Quota	Unlimited	Unlimited	Daily	0	0	Passive	When Close the Tab	1		Edit Delete
epati	Unlimited	Unlimited	Daily	0	0	Passive	When Close the Tab	1	03.03.2023 10:27	Edit Delete

< < 1 > >

Go

User Quotas New Record

User Informations	Select... ▼
Period	Daily ▼
Duration	Unlimited ▼
Quota	Unlimited ▼
One Time	<input checked="" type="checkbox"/> Closed
Max Login Limit per Person	<input type="text" value="1"/>
URL to open in new tab	<input type="text" value="https://www.google.com"/>
Logout Option	Optional (Conscious) ▼

The user session remains open unless consciously logged out from the client screen. If there is no traffic for 15 minutes, the session will end automatically.

AREA	EXPLANATION
User information	The user to be added is selected.
Period	The reset range of the defined quota (or quotas) is entered. One of the daily, weekly, monthly and annual options should be selected.
Time	It is determined how much time it will be used during the defined period. Two options are presented as time and indefinitely. If the duration option is selected, the user is expected to enter data in time and minute.
Quota	It is determined how much data will be used during the defined period. There are two options, quota and without jeans. If the quota option is selected, the user is expected to enter data in MBYTE (Megabyte).
Disposable Session	Open or closed.
Signing limit per person	Hotspot defined how many times the person can log in.
URL to open in new tab	The site to be opened in the new tab is written.
Logging option	There are three options. These options are described as optional (conscious), closing the tab and automatically off.

User Agreement

User is the section where the contract details will be written. The “user agreement approval” is activated after the settings have been recorded and settings are recorded. Hotspot is shown when clicking the “Contract Details” section on the login screen.

Open Hotspot Sessions,Hotspot MonitorYou can follow page
The Bandwidth Monitor Service must be started in order for the quota information to be processed smoothly!

Hotspot Settings

User Quotas

User Contract

User Agreement Approval [Save Settings](#)



Kullanıcı Sözleşmesi Belirtilmemiş.

Note: The user will not be able to log in unless he approves the contract on the Hotspot login screen.

Hotspot Login screen



Gender Female Male

ID Number

Name

Surname

Date of Birth

Telephone Number

eMail

Nationality

Client Type

Client Group

ePati Cyber Security Technologies Inc.
Mersin Universitesi Ciftlikkoy Kampusu
Teknopark Idari Binası Kat: 4 No: 411
Zip Code: 33343 Yenisehir / MERSIN / TURKIYE

www.epati.com.tr
info@epati.com.tr
+90 324 361 02 33
+90 324 361 02 39

