

Ip Pool

Product: Antikor v2 - Layer2 Tunnel Backbone
Guides

Ip Pool

The IP address ranges for network(s) to be managed are defined in this menu. These intervals will be used in the Antikor's control mechanisms.

The IP addresses desired to be used must be added to the IP address pools in advance. Some operations (such as Client Definitions, Static NAT) cannot be done without adding IP addresses to IP pools.

IP Pools Reload + Add

XLS CSV PDF Filter Clear

#	Ethernet	IP Block	Description	Transactions
1	DMZ1	10.100.100.0/24	10.2.1.128/25	Edit Delete
2	DMZ1	10.2.1.40/30	dmz	Edit Delete
3	LAN1	192.168.2.0/24	lan	Edit Delete
4	WAN1	10.2.1.0/24	wan	Edit Delete

« < 1 > »

IP Pools New Record

IP Pools - New Record ×

Ethernet

Address Family IPv4 IPv6

IP Block

Description

[Cancel](#) [Save](#)

FIELD	DESCRIPTION
Ethernet	Choose the Ethernet interface to be used by defined IP addresses.
Address Family	Choose the IP address block to be defined.
IP Address Block	Enter the IP address block to be defined.
Description	Enter description.



